

## Standards and other Regulations

### Standardization and standards terms

Standardization is the systematic achievement of uniformity of material and non-material objects, such as components, calculation methods, process flows and services for the benefit of the general public.

Standards term	Example	Explanation
Standard	DIN 7157	A standard is the published work of standardization, e.g. the selection of particular fits in DIN 7157.
Part	DIN 30910-2	Standards can comprise several parts associated with each other. The part numbers are appended to the main standard number with hyphens. DIN 30910-2 describes sintered materials for filters for example, whereas Part 3 and 4 deal with sintered materials for bearings and formed parts.
Supplement	DIN 743 Suppl. 1	A supplement contains information for a standard, however no additional specifications. The supplement DIN 743 Suppl. 1, for example, contains application examples of load capacity calculations for shafts and axles described in DIN 743.
Draft	E DIN 743 (2008-10)	Draft standards are made available to the public for examination and commenting. The planned new version of DIN 743 on load-bearing calculations of shafts and axles, for example, has been published since October 2008 as Draft E DIN 743.
Preliminary standard	DIN V 66304 (1991-04)	A preliminary standard contains the results of standardization, which have not been released as a standard because of certain provisos. DIN V 66304, for example, discusses a format for exchange of standard part data for computer-aided design.
Issue date	DIN 76-1 (2004-06)	Date of publication which is made public in the DIN publication guide; this is the date at which time the standard becomes valid. DIN 76-1, which sets undercuts for metric ISO threads has been valid since June 2004 for example.

### Types of standards and regulations (selection)

Type	Abbreviation	Explanation	Purpose and contents
International Standards (ISO standards)	ISO	International Organization for Standardization, Geneva (O and S are reversed in the abbreviation)	Simplifies the international exchange of goods and services, as well as cooperation in scientific, technical and economic areas.
European Standards (EN standards)	EN	European Committee for Standardization (Comité Européen de Normalisation), Brussels	Technical harmonization and the associated reduction of trade barriers for the advancement of the European market and the coalescence of Europe.
German Standards (DIN standards)	DIN	Deutsches Institut für Normung e.V., Berlin (German Institute for Standardization)	National standardization facilitates rationalization, quality assurance, environmental protection and common understanding in economics, technology, science, management and public relations.
	DIN EN	European standard for which the German version has attained the status of a German standard.	
	DIN ISO	German standard for which an international standard has been adopted without change.	
	DIN EN ISO	European standard for which an international standard has been adopted unchanged and the German version has the status of a German standard.	
	DIN VDE	Printed publication of the VDE, which has the status of a German standard.	
VDI Guidelines	VDI	Verein Deutscher Ingenieure e.V., Düsseldorf (Association of German Engineers)	These guidelines give an account of the current state of the art in specific subject areas and contain, for example, concrete procedural guidelines for the performing calculations or designing processes in mechanical or electrical engineering.
VDE printed publications	VDE	Verband Deutscher Elektrotechniker e.V., Frankfurt (Association for Electrical, Electronic & Information Technologies)	
DGQ publications	DGQ	Deutsche Gesellschaft für Qualität e.V., Frankfurt (German Society for Quality)	Recommendations in the area of quality technology.
REFA sheets	REFA	Association for Work Design, Industrial Organization and Corporate Development REFA e.V., Darmstadt	Recommendations in the area of production and work planning.

# 1 Mathematics

M

Quantity	Symbol	Unit	
		Name	Symbol
Lengths	$l$	meter	m

**1.1 Units of measurement**  
 SI base quantities and base units . . . . . 10  
 Derived quantities and their units . . . . . 11  
 Non-SI units . . . . . 12

**Surface area**

$$A_s = \pi \cdot d \cdot h + 2 \cdot \frac{\pi \cdot d^2}{4}$$


**Lateral surface area**

$$A_M = \pi \cdot d \cdot h$$

**1.2 Formulas**  
 Formula symbols, mathematical symbols . . . . . 13  
 Formulas, equations, graphs . . . . . 14  
 Transformation of formulas . . . . . 15  
 Quantities and units . . . . . 16  
 Calculation with quantities . . . . . 17  
 Percentage and interest calculation . . . . . 17

<b>sine</b>	=	$\frac{\text{opposite side}}{\text{hypotenuse}}$
<b>cosine</b>	=	$\frac{\text{adjacent side}}{\text{hypotenuse}}$
<b>tangent</b>	=	$\frac{\text{opposite side}}{\text{adjacent side}}$


**1.3 Angels and triangel**  
 Types of angels, sum of angels in a triangle . . . . . 18  
 Theorem of intersecting lines . . . . . 18  
 Functions of right triangles . . . . . 19  
 Functions of oblique triangles . . . . . 19




**1.4 Lengths**  
 Division of lengths . . . . . 20  
 Spring wire lengths . . . . . 21  
 Rough lengths . . . . . 21




**1.5 Areas**  
 Angular areas . . . . . 22  
 Triangle, polygon, circle . . . . . 23  
 Circular sector, circular segment . . . . . 24  
 Ellipse . . . . . 24



**1.6 Volume and surface area**  
 Cube, cylinder, pyramid . . . . . 25  
 Truncated pyramid, cone, truncated cone, sphere . . . . . 26  
 Volumes of composite solids . . . . . 27



**1.7 Mass**  
 General calculations . . . . . 27  
 Linear mass density . . . . . 27  
 Area mass density . . . . . 27



**1.8 Centroids**  
 Centroids of lines . . . . . 28  
 Centroids of plane areas . . . . . 28

## Units of measurement

### SI<sup>1)</sup> Base quantities and base units

cf. DIN 1301-1 (2010-10), -2 (1978-02), -3 (1979-10)

Base quantity	Length	Mass	Time	Electric current	Thermo-dynamic temperature	Amount of substance	Luminous intensity
Base units	meter	kilo-gram	second	ampere	kelvin	mole	candela
Unit symbol	m	kg	s	A	K	mol	cd

<sup>1)</sup> The units for measurement are defined in the International System of Units SI (Système International d'Unités). It is based on the seven basic units (SI units), from which other units are derived.

### Base quantities, derived quantities and their units

Quantity	Symbol	Unit		Relationship	Remarks Examples of application
		Name	Symbol		
<b>Length, Area, Volume, Angle</b>					
Length	<i>l</i>	meter	m	1 m = 10 dm = 100 cm = 1000 mm 1 mm = 1000 μm 1 km = 1000 m	1 inch = 25.4 mm In aviation and nautical applications the following applies: 1 international nautical mile = 1852 m
Area	<i>A, S</i>	square meter are hectare	m <sup>2</sup> a ha	1 m <sup>2</sup> = 10 000 cm <sup>2</sup> = 1 000 000 mm <sup>2</sup> 1 a = 100 m <sup>2</sup> 1 ha = 100 a = 10 000 m <sup>2</sup> 100 ha = 1 km <sup>2</sup>	Symbol <i>S</i> only for cross-sectional areas Are and hectare only for land
Volume	<i>V</i>	cubic meter liter	m <sup>3</sup> l, L	1 m <sup>3</sup> = 1000 dm <sup>3</sup> = 1 000 000 cm <sup>3</sup> 1 l = 1 L = 1 dm <sup>3</sup> = 10 dl = 0.001 m <sup>3</sup> 1 ml = 1 cm <sup>3</sup>	Mostly for fluids and gases
Plane angle (angle)	<i>α, β, γ ...</i>	radian  degrees  minutes  seconds	rad  °  '  "	1 rad = 1 m/m = 57.2957...° = 180°/π 1° = $\frac{\pi}{180}$ rad = 60' 1' = 1°/60 = 60" 1" = 1'/60 = 1°/3600	1 rad is the angle formed by the intersection of a circle around the center of 1 m radius with an arc of 1 m length. In technical calculations instead of $\alpha = 33^\circ 17' 27.6''$ , better use is $\alpha = 33.291^\circ$ .
Solid angle	<i>Ω</i>	steradian	sr	1 sr = 1 m <sup>2</sup> /m <sup>2</sup>	An object whose extension measures 1 rad in one direction and perpendicularly to this also 1 rad, covers a solid angle of 1 sr.
<b>Mechanics</b>					
Mass	<i>m</i>	kilogram gram  megagram metric ton	kg g  Mg t	1 kg = 1000 g 1 g = 1000 mg  1 metric t = 1000 kg = 1 Mg 0.2 g = 1 ct	Mass in the sense of a scale result or a weight is a quantity of the type of mass (unit kg).  Mass for precious stones in carat (ct).
Linear mass density	<i>m'</i>	kilogram per meter	kg/m	1 kg/m = 1 g/mm	For calculating the mass of bars, profiles, pipes.
Area mass density	<i>m''</i>	kilogram per square meter	kg/m <sup>2</sup>	1 kg/m <sup>2</sup> = 0.1 g/cm <sup>2</sup>	To calculate the mass of sheet metal.
Density	<i>ρ</i>	kilogram per cubic meter	kg/m <sup>3</sup>	1000 kg/m <sup>3</sup> = 1 metric t/m <sup>3</sup> = 1 kg/dm <sup>3</sup> = 1 g/cm <sup>3</sup> = 1 g/ml = 1 mg/mm <sup>3</sup>	The density is a quantity independent of location.

## Units of measurement

### Quantities and Units (continued)

Quantity	Symbol	Unit Name	Symbol	Relationship	Remarks Examples of application
<b>Mechanics</b>					
Moment of inertia, 2nd Moment of mass	$J$	kilogram x square meter	$\text{kg} \cdot \text{m}^2$	The following applies for a homogenous body: $J = \rho \cdot r^2 \cdot V$	The moment of inertia (2nd moment of mass) is dependent upon the total mass of the body as well as its form and the position of the axis of rotation.
Force	$F$	newton	N	$1 \text{ N} = 1 \frac{\text{kg} \cdot \text{m}}{\text{s}^2} = 1 \frac{\text{J}}{\text{m}}$	The force 1 N effects a change in velocity of 1 m/s in 1 s in a 1 kg mass.
Weight	$F_G, G$			$1 \text{ MN} = 10^3 \text{ kN} = 1\,000\,000 \text{ N}$	
Torque Bending mom. Torsional mom.	$M, M_b, T$	newton x meter	$\text{N} \cdot \text{m}$	$1 \text{ N} \cdot \text{m} = 1 \frac{\text{kg} \cdot \text{m}^2}{\text{s}^2}$	$1 \text{ N} \cdot \text{m}$ is the moment that a force of 1 N effects with a lever arm of 1 m.
Momentum	$p$	kilogram x meter per second	$\text{kg} \cdot \text{m/s}$	$1 \text{ kg} \cdot \text{m/s} = 1 \text{ N} \cdot \text{s}$	The momentum is the product of the mass times velocity. It has the direction of the velocity.
Pressure  Mechanical stress	$p, \sigma, \tau$	pascal  newton per square millimeter	Pa  $\text{N/mm}^2$	$1 \text{ Pa} = 1 \text{ N/m}^2 = 0.01 \text{ mbar}$ $1 \text{ bar} = 100\,000 \text{ N/m}^2 = 10 \text{ N/cm}^2 = 10^5 \text{ Pa}$ $1 \text{ mbar} = 1 \text{ hPa}$ $1 \text{ N/mm}^2 = 10 \text{ bar} = 1 \text{ MN/m}^2 = 1 \text{ MPa}$ $1 \text{ daN/cm}^2 = 0.1 \text{ N/mm}^2$	Pressure refers to the force per unit area. For gage pressure the symbol $p_g$ is used (DIN 1314). $1 \text{ bar} = 14.5 \text{ psi}$ (pounds per square inch)
Second moment of area	$I$	meter to the fourth power centimeter to the fourth power	$\text{m}^4$  $\text{cm}^4$	$1 \text{ m}^4 = 100\,000\,000 \text{ cm}^4$	Previously: Geometrical moment of inertia
Energy, Work, Quantity of heat	$E, W$	joule	J	$1 \text{ J} = 1 \text{ N} \cdot \text{m} = 1 \text{ W} \cdot \text{s} = 1 \text{ kg} \cdot \text{m}^2/\text{s}^2$	Joule for all forms of energy, $\text{kW} \cdot \text{h}$ preferred for electrical energy.
Power Heat flux	$P, \Phi$	watt	W	$1 \text{ W} = 1 \text{ J/s} = 1 \text{ N} \cdot \text{m/s} = 1 \text{ V} \cdot \text{A} = 1 \text{ m}^2 \cdot \text{kg/s}^3$	Power describes the work which is achieved within a specific time.
<b>Time</b>					
Time, Time span, Duration	$t$	<b>seconds</b> minutes hours day year	s min h d a	$1 \text{ min} = 60 \text{ s}$ $1 \text{ h} = 60 \text{ min} = 3600 \text{ s}$ $1 \text{ d} = 24 \text{ h} = 86\,400 \text{ s}$	3 h means a time span (3 hrs.), $3^{\text{h}}$ means a point in time (3 o'clock). If points in time are written in mixed form, e.g. $3^{\text{h}}24^{\text{m}}10^{\text{s}}$ , the symbol min can be shortened to m.
Frequency	$f, \nu$	hertz	Hz	$1 \text{ Hz} = 1/\text{s}$	$1 \text{ Hz} \approx 1$ cycle in 1 second.
Rotational speed, Rotational frequency	$n$	1 per second  1 per minute	1/s  1/min	$1/\text{s} = 60/\text{min} = 60 \text{ min}^{-1}$ $1/\text{min} = 1 \text{ min}^{-1} = \frac{1}{60 \text{ s}}$	The number of revolutions per unit of time gives the revolution frequency, also called rpm.
Velocity	$v$	meters per second meters per minute kilometers per hour	m/s  m/min  km/h	$1 \text{ m/s} = 60 \text{ m/min} = 3.6 \text{ km/h}$ $1 \text{ m/min} = \frac{1 \text{ m}}{60 \text{ s}}$ $1 \text{ km/h} = \frac{1 \text{ m}}{3.6 \text{ s}}$	Nautical velocity in knots (kn): $1 \text{ kn} = 1.852 \text{ km/h}$ miles per hour = 1 mile/h = 1 mph $1 \text{ mph} = 1.60934 \text{ km/h}$
Angular-velocity	$\omega$	1 per second radians per second	1/s rad/s	$\omega = 2\pi \cdot n$	For a rpm of $n = 2/\text{s}$ the angular velocity $\omega = 4\pi/\text{s}$ .
Acceleration	$a, g$	meters per second squared	$\text{m/s}^2$	$1 \text{ m/s}^2 = \frac{1 \text{ m/s}}{1 \text{ s}}$	Symbol g only for acceleration due to gravity. $g = 9.81 \text{ m/s}^2 \approx 10 \text{ m/s}^2$

## Units of measurement

### Quantities and units (continued)

Quantity	Sym- bol	Unit Name	Sym- bol	Relationship	Remarks Examples of application
<b>Electricity and Magnetism</b>					
Electric current Electromotive force Electrical resistance Electrical conductance	$I$	<b>ampere</b>	A	$1 \text{ V} = 1 \text{ W}/1 \text{ A} = 1 \text{ J}/\text{C}$	The motion of an electrical charge is called current. The electromotive force is equal to the potential difference between two points in an electric field. The reciprocal of the electrical resistance is called the electrical conductivity.
	$E$	volt	V	$1 \Omega = 1 \text{ V}/1 \text{ A}$	
	$R$	ohm	$\Omega$	$1 \text{ S} = 1 \text{ A}/1 \text{ V} = 1/\Omega$	
	$G$	siemens	S		
Specific resistance Conductivity	$\rho$	ohm x meter	$\Omega \cdot \text{m}$	$10^{-6} \Omega \cdot \text{m} = 1 \Omega \cdot \text{mm}^2/\text{m}$	$\rho = \frac{1}{\kappa} \text{ in } \frac{\Omega \cdot \text{mm}^2}{\text{m}}$ $\kappa = \frac{1}{\rho} \text{ in } \frac{\text{m}}{\Omega \cdot \text{mm}^2}$
	$\gamma, \kappa$	siemens per meter	S/m		
Frequency	$f$	hertz	Hz	$1 \text{ Hz} = 1/\text{s}$ $1000 \text{ Hz} = 1 \text{ kHz}$	Frequency of public electric utility: EU 50 Hz, USA/Canada 60 Hz
Electrical energy	$W$	joule	J	$1 \text{ J} = 1 \text{ W} \cdot \text{s} = 1 \text{ N} \cdot \text{m}$ $1 \text{ kW} \cdot \text{h} = 3.6 \text{ MJ}$ $1 \text{ W} \cdot \text{h} = 3.6 \text{ kJ}$	In atomic and nuclear physics the unit eV (electron volt) is used.
Phase difference	$\varphi$	–	–	for alternating current: $\cos \varphi = \frac{P}{U \cdot I}$	The angle between current and voltage in inductive or capacitive load.
Elect. field strength Elect. charge Elect. capacitance inductance	$E$ $Q$ $C$ $L$	volts per meter coulomb farad henry	V/m C F H	$1 \text{ C} = 1 \text{ A} \cdot 1 \text{ s}; 1 \text{ A} \cdot \text{h} = 3.6 \text{ kC}$ $1 \text{ F} = 1 \text{ C}/\text{V}$ $1 \text{ H} = 1 \text{ V} \cdot \text{s}/\text{A}$	$E = \frac{F}{Q}, C = \frac{Q}{U}, Q = I \cdot t$
Power Effective power	$P$	watt	W	$1 \text{ W} = 1 \text{ J}/\text{s} = 1 \text{ N} \cdot \text{m}/\text{s}$ $= 1 \text{ V} \cdot \text{A}$	In electrical power engineering: Apparent power $S$ in $\text{V} \cdot \text{A}$
Quantity	Sym- bol	Unit Name	Sym- bol	Relationship	Remarks Examples of application
<b>Electricity and Magnetism</b>					
Thermo- dynamic temperature Celsius temperature	$T, \theta$	<b>kelvin</b>	K	$0 \text{ K} = -273.15 \text{ }^\circ\text{C}$	Kelvin (K) and degrees Celsius ( $^\circ\text{C}$ ) are used for temperatures and temperature differences. $t = T - T_0; T_0 = 273.15 \text{ K}$ degrees Fahrenheit ( $^\circ\text{F}$ ): $1.8 \text{ }^\circ\text{F} = 1 \text{ }^\circ\text{C}$
	$t, \vartheta$	degrees Celsius	$^\circ\text{C}$	$0 \text{ }^\circ\text{C} = 273.15 \text{ K}$ $0 \text{ }^\circ\text{C} = 32 \text{ }^\circ\text{F}$ $0 \text{ }^\circ\text{F} = -17.77 \text{ }^\circ\text{C}$	
Quantity of heat	$Q$	joule	J	$1 \text{ J} = 1 \text{ W} \cdot \text{s} = 1 \text{ N} \cdot \text{m}$ $1 \text{ kW} \cdot \text{h} = 3600000 \text{ J} = 3,6 \text{ MJ}$	$1 \text{ kcal} \approx 4.1868 \text{ kJ}$
Net calorific value	$H_u$	joule per kilogram Joule per cubic meter	J/kg J/m <sup>3</sup>	$1 \text{ MJ}/\text{kg} = 1000000 \text{ J}/\text{kg}$ $1 \text{ MJ}/\text{m}^3 = 1000000 \text{ J}/\text{m}^3$	Thermal energy released per kg fuel minus the heat of vaporization of the water vapor contained in the exhaust gases.
<b>Non-SI units</b>					
Length	Area	Volume	Mass	Energy, Power	
1 inch (in) = 25.4 mm	1 sq.in = 6.452 cm <sup>2</sup>	1 cu.in = 16.39 cm <sup>3</sup>	1 oz = 28.35 g	1 PSh = 0.735 kWh	
1 foot (ft) = 0.3048 m	1 sq.ft = 9.29 dm <sup>2</sup>	1 cu.ft = 28.32 dm <sup>3</sup>	1 lb = 453.6 g	1 PS = 735 W	
1 yard (yd) = 0.9144 m	1 sq.yd = 0.8361 m <sup>2</sup>	1 cu.yd = 764.6 dm <sup>3</sup>	1 t = 1000 kg	1 kcal = 4186.8 Ws	
1 nautical mile = 1.852 km	1 acre = 4046.856 m <sup>2</sup>	1 gallon (US) = 3.785 l	1 short ton = 907.2 kg	1 kcal = 1.166 Wh	
1 mile = 1.6093 km	<b>Pressure</b>	1 gallon (UK) = 4.546 l	1 Karat = 0.2 g	1 kpm/s = 9.807 W	
	1 bar = 14.5 pound/in <sup>2</sup>	1 barrel = 158.8 l	1 pound/in <sup>3</sup> = 27.68 g/cm <sup>3</sup>	1 Btu = 1055 Ws	
	1 N/mm <sup>2</sup> = 145.038 pound/in <sup>2</sup>			1 hp = 745.7 W	

## Formula symbols, Mathematical symbols

### Formula symbols

cf. DIN 1304-1 (1994-03)

Formula symbol	Meaning	Formula symbol	Meaning	Formula symbol	Meaning
<b>Length, Area, Volume, Angle</b>					
$l$	Length	$r, R$	Radius	$\alpha, \beta, \gamma$	Planar angle
$w$	Width	$d, D$	Diameter	$\Omega$	Solid angle
$h$	Height	$A, S$	Area, Cross-sectional area	$\lambda$	Wave length
$s$	Linear distance	$V$	Volume		
<b>Mechanics</b>					
$m$	Mass	$F$	Force	$G$	Shear modulus
$m'$	Linear mass density	$F_W, W$	Gravitational force, Weight	$\mu, f$	Coefficient of friction
$m''$	Area mass density	$M$	Torque	$W$	Section modulus
$\rho$	Density	$T$	Torsional moment	$I$	Second moment of an area
$J$	Moment of inertia	$M_b$	Bending moment	$W, E$	Work, Energy
$p$	Pressure	$\sigma$	Normal stress	$W_p, E_p$	Potential energy
$p_{abs}$	Absolute pressure	$\tau$	Shear stress	$W_k, E_k$	Kinetic energy
$p_{amb}$	Ambient pressure	$\varepsilon$	Normal strain	$P$	Power
$p_g$	Gage pressure	$E$	Modulus of elasticity	$\eta$	Efficiency
<b>Time</b>					
$t$	Time, Duration	$f, \nu$	Frequency	$a$	Acceleration
$T$	Cycle duration	$v, u$	Velocity	$g$	Gravitational acceleration
$n$	Revolution frequency, Speed	$\omega$	Angular velocity	$\alpha$	Angular acceleration
				$Q, V, q_v$	Volumetric flow rate
<b>Electricity</b>					
$Q$	Electric charge, Quantity of electricity	$L$	Inductance	$X$	Reactance
$E$	Electromotive force	$R$	Resistance	$Z$	Impedance
$C$	Capacitance	$\rho$	Specific resistance	$\varphi$	Phase difference
$I$	Electric current	$\gamma, \kappa$	Electrical conductivity	$N$	Number of turns
<b>Heat</b>					
$T, \Theta$	Thermodynamic temperature	$Q$	Heat, Quantity of heat	$\Phi, \dot{Q}$	Heat flow
$\Delta T, \Delta t, \Delta \delta$	Temperature difference	$\lambda$	Thermal conductivity	$a$	Thermal diffusivity
$t, \delta$	Celsius temperature	$\alpha$	Heat transition coefficient	$c$	Specific heat
$\alpha_1, \alpha$	Coefficient of linear expansion	$k$	Heat transmission coefficient	$H_{net}$	Net calorific value
<b>Light, Electromagnetic radiation</b>					
$E$	Illuminance	$f$	Focal length	$I$	Luminous intensity
		$n$	Refractive index	$Q, W$	Radiant energy
<b>Acoustics</b>					
$p$	Acoustic pressure	$L_p$	Acoustic pressure level	$N$	Loudness
$c$	Acoustic velocity	$I$	Sound intensity	$L_N$	Loudness level
<b>Mathematical symbols</b>					
cf. DIN 1302 (1999-12)					
Math. symbol	Spoken	Math. symbol	Spoken	Math. symbol	Spoken
$\approx$	approx. equals, around, about	$\sim$	proportional	$\log$	logarithm (general)
$\doteq$	equivalent to	$\sqrt{\quad}$	a to the n-th power, the n-th power of a	$\lg$	common logarithm
$\dots$	and so on, etc.	$\sqrt[n]{\quad}$	square root of	$\ln$	natural logarithm
$\infty$	infinity		n-th root of	$e$	Euler number (e = 2.718281...)
$=$	equal to	$ x $	absolute value of x	$\sin$	sine
$\neq$	not equal to	$\perp$	perpendicular to	$\cos$	cosine
$\stackrel{\text{def}}{=}$	is equal to by definition	$\parallel$	is parallel to	$\tan$	tangent
$<$	less than	$\uparrow \uparrow$	parallel in the same direction	$\cot$	cotangent
$\leq$	less than or equal to	$\updownarrow$	parallel in the opposite direction	$( ), [ ], \{ }$	parentheses, brackets open and closed
$>$	greater than	$\sphericalangle$	angle	$\pi$	pi (circle constant = 3.14159 ...)
$\geq$	greater than or equal to	$\triangle$	triangle		
$+$	plus	$\cong$	congruent to		
$-$	minus	$\Delta x$	delta x (difference between two values)	$\overline{AB}$	line segment AB
$\cdot$	times, multiplied by	$\%$	percent, of a hundred	$\overset{\frown}{AB}$	arc AB
$-, /, :, \div$	over, divided by, per, to	$\text{‰}$	per mil, of a thousand	$a', a''$	a prime, a double prime
$\Sigma$	sigma (summation)			$a_1, a_2$	a sub 1, a sub 2

# Formulas, Equations, Graphs

## Formulas

In most cases, the calculation of physical quantities is done with the help of formulas. They consist of:

- Formula symbols, e.g.  $v_c$  for cutting velocity,  $d$  for diameter,  $n$  for speed
- Operators (calculation rules), e.g.  $\cdot$  for multiplication,  $+$  for addition,  $-$  for subtraction and  $-$  (fraction line) for division
- Constants, e.g.  $\pi$  (pi) = 3.14159 ...
- Numbers, e.g. 10, 15 ...

The formula symbols (page 13) are wildcards for quantities. When solving mathematical problems, the known quantities with their units are filled in the formulas. Before or during the calculation process, the units are converted in a way that

- the calculation becomes feasible or
- the result comprises the required unit.

Most quantities and units are standardized (page 10).

The **result** is always a **numerical value** accompanied by a **unit**, e.g. 4.5 m, 15 s

### Example:

What is the cutting velocity  $v_c$  in m/min for  $d = 200$  mm and  $n = 630$ /min?

$$v_c = \pi \cdot d \cdot n = \pi \cdot 200 \text{ mm} \cdot 630 \frac{1}{\text{min}} = \pi \cdot 200 \text{ mm} \cdot \frac{1 \text{ m}}{1000 \text{ mm}} \cdot 630 \frac{1}{\text{min}} = 395.84 \frac{\text{m}}{\text{min}}$$

### Formula for cutting velocity

$$v_c = \pi \cdot d \cdot n$$

## Numerical value equations

Numerical value equations or numerical equations are formulas in which the typical conversions of units have already been integrated. The following should be noted when using equations:

The numerical values of the individual quantities may only be used in combination with the designated unit.

- The units are not carried along in the calculation.
- The unit of the quantity to be obtained is predetermined.

### Example:

What is the torque  $M$  of an electrical motor with a driving power of  $P = 15$  kW and a speed of  $n = 750$ /min?

$$M = \frac{9550 \cdot P}{n} = \frac{9550 \cdot 15}{750} \text{ N} \cdot \text{m} = 191 \text{ N} \cdot \text{m}$$


### Numerical value equation for torque

$$M = \frac{9550 \cdot P}{n}$$

Designated unit	
Designation	Unit
$M$	Torque N · m
$P$	Power kW
$n$	Speed 1/min

## Equations and graphs

In functional equations,  $y$  is the function of  $x$ , with  $x$  as an independent and  $y$  as a dependent variable. The number pairs  $(x, y)$  of a value table form a graph in the  $x$ - $y$  system of coordinates.



### 1<sup>st</sup> example:

$$y = 0.5x + 1$$

$x$	-2	0	2	3
$y$	0	1	2	2.5

### 2<sup>nd</sup> example:


#### Cost function and revenue function

$$C_t = 60 \text{ \$/piece} \cdot Q + 200000 \text{ \$}$$

$$R = 110 \text{ \$/piece} \cdot Q$$

$Q$	0	4000	6000
$C_t$	200000	440000	560000
$R$	0	440000	660000

- $C_t$  total costs  $\rightarrow$  dependent variable
- $Q$  quantity  $\rightarrow$  independent variable
- $C_f$  fixed costs  $\rightarrow$  y coordinate section
- $C_v$  variable costs  $\rightarrow$  gradient of the function
- $R$  revenue  $\rightarrow$  dependent variable



### Assigned function

$$y = f(x)$$

### Linear function

$$y = m \cdot x + b$$

### Examples:

#### Cost function

$$C_t = C_v \cdot Q + C_f$$

#### Revenue function

$$R = R/\text{piece} \cdot Q$$

## Transformation of formulas

### Transformation of formulas

Formulas and numerical equations are transformed so that the quantity to be obtained stands alone on the left side of the equation. The value of the left side and right side of the formula must not change during the transformation. The following rule applies to all steps of the formula transformation.

Changes applied to the left formula side	=	Changes applied to the right formula side
---	---	--

*Formula*

$$P = \frac{F \cdot s}{t}$$

left side of the formula = right side of the formula

To be able to trace each step of the transformation, it is useful to mark it to the right next to the formula:

$\cdot t$  → both sides of the formula are multiplied by  $t$ .

$: F$  → both sides of the formula are divided by  $F$ .

### Transformations of sums

**Example:** formula  $L = l_1 + l_2$ , transformation to find  $l_2$

$\boxed{1} \quad L = l_1 + l_2 \quad   -l_1 \quad \text{subtract } l_1$	$\boxed{3} \quad L - l_1 = l_2 \quad \text{invert both sides}$
$\boxed{2} \quad L - l_1 = l_1 + l_2 - l_1 \quad \text{perform subtraction}$	$\boxed{4} \quad l_2 = L - l_1 \quad \text{transformed formula}$

### Transformations of products

**Example:** formula  $A = l \cdot b$ , transformation to find  $l$

$\boxed{1} \quad A = l \cdot b \quad   : b \quad \text{divide by } b$	$\boxed{3} \quad \frac{A}{b} = l \quad \text{invert both sides}$
$\boxed{2} \quad \frac{A}{b} = \frac{l \cdot b}{b} \quad \text{cancel } b$	$\boxed{4} \quad l = \frac{A}{b} \quad \text{transformed formula}$

### Transformations of fractions

**Example:** formula  $n = \frac{l}{l_1 + s}$ , transformation to find  $s$

$\boxed{1} \quad n = \frac{l}{l_1 + s} \quad   \cdot (l_1 + s) \quad \text{multiply by } (l_1 + s)$	$\boxed{4} \quad n \cdot l_1 - n \cdot l_1 + n \cdot s = l - n \cdot l_1 \quad   : n \quad \text{subtract divide by } n$
$\boxed{2} \quad n \cdot (l_1 + s) = \frac{l \cdot (l_1 + s)}{(l_1 + s)} \quad \text{cancel } (l_1 + s) \text{ on the right side solve the term in brackets}$	$\boxed{5} \quad \frac{s \cdot n}{n} = \frac{l - n \cdot l_1}{n} \quad \text{cancel } n$
$\boxed{3} \quad n \cdot l_1 + n \cdot s = l \quad   - n \cdot l_1 \quad \text{subtract } -n \cdot l_1$	$\boxed{6} \quad s = \frac{l - n \cdot l_1}{n} \quad \text{transformed formula}$

### Transformations of roots


**Example:** formula  $c = \sqrt{a^2 + b^2}$ , transformation to find  $a$

$\boxed{1} \quad c = \sqrt{a^2 + b^2} \quad   ( )^2 \quad \text{square equation}$	$\boxed{4} \quad a^2 = c^2 - b^2 \quad   \sqrt{\quad} \quad \text{extract the root}$
$\boxed{2} \quad c^2 = a^2 + b^2 \quad   - b^2 \quad \text{subtract } b^2$	$\boxed{5} \quad \sqrt{a^2} = \sqrt{c^2 - b^2} \quad \text{simplify the expression}$
$\boxed{3} \quad c^2 - b^2 = a^2 + b^2 - b^2 \quad \text{subtract, invert both sides}$	$\boxed{6} \quad a = \sqrt{c^2 - b^2} \quad \text{transformed formula}$



## Quantities and units

### Numerical values and units



Physical quantities, e.g. 125 mm, consist of a

- **numerical value**, which is determined by measurement or calculation, and a
- **unit**, e.g. m, kg

Units are standardized in accordance with DIN 1301-1 (page 10).

Very large or very small numerical values may be represented in a simplified way as decimal multiples or factors with the help of prefixes, e.g. 0.004 mm = 4  $\mu$ m.

### Decimal multiples or factors of units

cf. DIN 1301-1 (2004-10)

Prefix		Power of ten	Mathematical designation	Examples
Symbol	Name			
T	tera	$10^{12}$	trillion	12 000 000 000 000 N = $12 \cdot 10^{12}$ N = 12 TN (teranewtons)
G	giga	$10^9$	billion	45 000 000 000 W = $45 \cdot 10^9$ W = 45 GW (gigawatts)
M	mega	$10^6$	million	8 500 000 V = $8.5 \cdot 10^6$ V = 8.5 MV (megavolts)
k	kilo	$10^3$	thousand	12 600 W = $12.6 \cdot 10^3$ W = 12.6 kW (kilowatts)
h	hecto	$10^2$	hundred	500 l = $5 \cdot 10^2$ l = 5 hl (hectoliters)
da	deca	$10^1$	ten	32 m = $3.2 \cdot 10^1$ m = 3.2 dam (decameters)
–	–	$10^0$	one	1.5 m = $1.5 \cdot 10^0$ m
d	deci	$10^{-1}$	tenth	0.5 l = $5 \cdot 10^{-1}$ l = 5 dl (deciliters)
c	centi	$10^{-2}$	hundredth	0.25 m = $25 \cdot 10^{-2}$ m = 25 cm (centimeters)
m	milli	$10^{-3}$	thousandth	0.375 A = $375 \cdot 10^{-3}$ A = 375 mA (milliamperes)
$\mu$	micro	$10^{-6}$	millionth	0.000 052 m = $52 \cdot 10^{-6}$ m = 52 $\mu$ m (micrometers)
n	nano	$10^{-9}$	billionth	0.000 000 075 m = $75 \cdot 10^{-9}$ m = 75 nm (nanometers)
p	pico	$10^{-12}$	trillionth	0.000 000 000 006 F = $6 \cdot 10^{-12}$ F = 6 pF (picofarads)

### Conversion of units

Calculations with physical units are only possible if these units refer to the same base in this calculation. When solving mathematical problems, units often must be converted to basic units, e.g. mm to m, s to h,  $\text{mm}^2$  to  $\text{m}^2$ . This is done with the help of conversion factors that represent the value 1 (coherent units).

### Conversion factors for units (excerpt)

Quantity	Conversion factors, e. g.	Quantity	Conversion factors, e. g.
Length	$1 = \frac{10 \text{ mm}}{1 \text{ cm}} = \frac{1000 \text{ mm}}{1 \text{ m}} = \frac{1 \text{ m}}{1000 \text{ mm}} = \frac{1 \text{ km}}{1000 \text{ m}}$	Time	$1 = \frac{60 \text{ min}}{1 \text{ h}} = \frac{3600 \text{ s}}{1 \text{ h}} = \frac{60 \text{ s}}{1 \text{ min}} = \frac{1 \text{ min}}{60 \text{ s}}$
Area	$1 = \frac{100 \text{ mm}^2}{1 \text{ cm}^2} = \frac{100 \text{ cm}^2}{1 \text{ dm}^2} =$	Angle	$1 = \frac{60'}{1^\circ} = \frac{60''}{1'} = \frac{3600''}{1^\circ} = \frac{1^\circ}{60 \text{ s}}$
Volume	$1 = \frac{1000 \text{ mm}^3}{1 \text{ cm}^3} = \frac{1000 \text{ cm}^3}{1 \text{ dm}^3} =$	Inch	1 inch = 25.4 mm; 1 mm = $\frac{1}{25.4}$ inches

#### 1<sup>st</sup> example:

Convert volume  $V = 3416 \text{ mm}^3$  to  $\text{cm}^3$ .

Volume  $V$  is multiplied by a conversion factor. Its numerator has the unit  $\text{cm}^3$  and its denominator the unit  $\text{mm}^3$ .

$$V = 3416 \text{ mm}^3 = \frac{1 \text{ cm}^3 \cdot 3416 \text{ mm}^3}{1000 \text{ mm}^3} = \frac{3416 \text{ cm}^3}{1000} = \mathbf{3.416 \text{ cm}^3}$$

#### 2<sup>nd</sup> example:

The angle size specification  $\alpha = 42^\circ 16'$  is to be expressed in degrees ( $^\circ$ ).


The partial angle  $16'$  must be converted to degrees ( $^\circ$ ). The value is multiplied by a conversion factor, the numerator of which has the unit degree ( $^\circ$ ) and the denominator the unit minute ( $'$ ).

$$\alpha = 42^\circ + 16' \cdot \frac{1^\circ}{60'} = 42^\circ + \frac{16 \cdot 1^\circ}{60} = 42^\circ + 0.267^\circ = \mathbf{42.267^\circ}$$



Types of angles, Theorem of intersecting lines, Angles in a triangle, Pythagorean theorem

Types of angles



- $g$  straight line
- $g_1, g_2$  parallel straight lines
- $\alpha, \beta$  corresponding angles
- $\beta, \delta$  opposite angles
- $\alpha, \delta$  alternate angles
- $\alpha, \gamma$  adjacent angles

If two parallels are intersected by a straight line, there are geometrical interrelationships between the resulting angles.

Corresponding angles

$$\alpha = \beta$$

Opposite angles

$$\beta = \delta$$

Alternate angles


$$\alpha = \delta$$

Adjacent angles

$$\alpha + \gamma = 180^\circ$$

Theorem of intersecting lines

$\tau_{to}$  outer torsional stress  
 $\tau_{ti}$  inner torsional stress



If two intersecting lines are intercepted by a pair of parallels, the resulting segments form equal ratios.

Example:

$D = 40 \text{ mm}, d = 30 \text{ mm},$   
 $\tau_{ta} = 135 \text{ N/mm}^2; \tau_{ti} = ?$

$$\frac{\tau_{ti}}{\tau_{to}} = \frac{d}{D} \Rightarrow \tau_{ti} = \frac{\tau_{to} \cdot d}{D}$$


$$= \frac{135 \text{ N/mm}^2 \cdot 30 \text{ mm}}{40 \text{ mm}} = 101.25 \text{ N/mm}^2$$

Theorem of intersecting lines

$$\frac{a_1}{a_2} = \frac{b_1}{b_2} = \frac{d}{D}$$

$$\frac{a_1}{b_1} = \frac{a_2}{b_2} \quad \frac{b_1}{d} = \frac{b_2}{D}$$

Sum of angles in a triangle



- $a, b, c$  sides of the triangle
- $\alpha, \beta, \gamma$  angles in the triangle

Example:


$\alpha = 21^\circ, \beta = 95^\circ, \gamma = ?$   
 $\gamma = 180^\circ - \alpha - \beta = 180^\circ - 21^\circ - 95^\circ = 64^\circ$

Sum of angles in a triangle

$$\alpha + \beta + \gamma = 180^\circ$$

In every triangle, the sum of the interior angles equals  $180^\circ$ .

Pythagorean theorem



In a **right triangle** the square on the hypotenuse is equal to the sum of the squares on the sides meeting the right angle.

- $a$  side
- $b$  side
- $c$  hypotenuse

1<sup>st</sup> example:

$c = 35 \text{ mm}; a = 21 \text{ mm}; b = ?$   
 $b = \sqrt{c^2 - a^2} = \sqrt{(35 \text{ mm})^2 - (21 \text{ mm})^2} = 28 \text{ mm}$

2<sup>nd</sup> example:

CNC programm with  $R = 50 \text{ mm}$  and  $I = 25 \text{ mm}$ .  
 $K = ?$   
 $c^2 = a^2 + b^2$   
 $R^2 = I^2 + K^2$   
 $K = \sqrt{R^2 - I^2} = \sqrt{50^2 \text{ mm}^2 - 25^2 \text{ mm}^2}$   
 $K = 43.3 \text{ mm}$

Length of the hypotenuse

$$c^2 = a^2 + b^2$$


Square on the hypotenuse

$$c = \sqrt{a^2 + b^2}$$

Length of the sides meeting the right angle


$$a = \sqrt{c^2 - b^2}$$

$$b = \sqrt{c^2 - a^2}$$



# Functions of triangles

## Functions of right triangles (trigonometric functions)



$c$  hypotenuse (longest side)  
 $a, b$  sides,  
 -  $b$  is the adjacent side of  $\alpha$   
 -  $a$  is the opposite side of  $\alpha$   
 $\alpha, \beta, \gamma$  angles in the triangle,  $\gamma = 90^\circ$   
 $\sin$  notation of sine  
 $\cos$  notation of cosine  
 $\tan$  notation of tangent  
 $\sin \alpha$  sine of angle  $\alpha$

### Trigonometric functions

<b>sine</b>	=	<b>opposite side</b>	<b>hypotenuse</b>
<b>cosine</b>	=	<b>adjacent side</b>	<b>hypotenuse</b>
<b>tangent</b>	=	<b>opposite side</b>	<b>adjacent side</b>


Relations applying to angle  $\alpha$ :

$\sin \alpha = \frac{a}{c}$	$\cos \alpha = \frac{b}{c}$	$\tan \alpha = \frac{a}{b}$
-----------------------------	-----------------------------	-----------------------------

Relations applying to angle  $\beta$ :

$\sin \beta = \frac{b}{c}$	$\cos \beta = \frac{a}{c}$	$\tan \beta = \frac{b}{a}$
----------------------------	----------------------------	----------------------------

The calculation of an angle in degrees ( $^\circ$ ) or as a circular measure (rad) is done with the help of inverse trigonometric functions, e. g. arcsine.



### 1st example

$L_1 = 150 \text{ mm}$ ,  $L_2 = 30 \text{ mm}$ ,  $L_3 = 140 \text{ mm}$ ;  
 angle  $\alpha = ?$

$$\tan \alpha = \frac{L_1 + L_2}{L_3} = \frac{180 \text{ mm}}{140 \text{ mm}} = 1.286$$


**Angle  $\alpha = 52^\circ$**

### 2nd example

$L_1 = 150 \text{ mm}$ ,  $L_2 = 30 \text{ mm}$ ,  $\alpha = 52^\circ$ ;  
 Length of the shock absorber  $L = ?$

$$L = \frac{L_1 + L_2}{\sin \alpha} = \frac{180 \text{ mm}}{\sin 52^\circ} = \mathbf{228.42 \text{ mm}}$$

## Functions of oblique triangles (law of sines, law of cosines)



According to the law of sines, the ratios of the sides correspond to the sine of their opposite angles in the triangle. If one side and two angles are known, the other values can be calculated with the help of this function.

Side  $a \rightarrow$  opposite angle  $\sin \alpha$   
 Side  $b \rightarrow$  opposite angle  $\sin \beta$   
 Hypotenuse  $c \rightarrow$  opposite angle  $\sin \gamma$


### Law of sines

$$a : b : c = \sin \alpha : \sin \beta : \sin \gamma$$

$$\frac{a}{\sin \alpha} = \frac{b}{\sin \beta} = \frac{c}{\sin \gamma}$$

There are many transformation options:

$a = \frac{b \cdot \sin \alpha}{\sin \beta} = \frac{c \cdot \sin \alpha}{\sin \gamma}$
$b = \frac{a \cdot \sin \beta}{\sin \alpha} = \frac{c \cdot \sin \beta}{\sin \gamma}$
$c = \frac{a \cdot \sin \gamma}{\sin \alpha} = \frac{b \cdot \sin \gamma}{\sin \beta}$



### Example:

$F = 800 \text{ N}$ ,  $\alpha = 40^\circ$ ,  $\beta = 38^\circ$ ;  $F_z = ?$ ,  $F_d = ?$

The forces are calculated with the help of the forces diagram.

$$\frac{F}{\sin \alpha} = \frac{F_z}{\sin \beta} \Rightarrow F_z = \frac{F \cdot \sin \beta}{\sin \alpha}$$

$$F_z = \frac{800 \text{ N} \cdot \sin 38^\circ}{\sin 40^\circ} = \mathbf{766.24 \text{ N}}$$

$$\frac{F}{\sin \alpha} = \frac{F_d}{\sin \gamma} \Rightarrow F_d = \frac{F \cdot \sin \gamma}{\sin \alpha}$$

$$F_d = \frac{800 \text{ N} \cdot \sin 102^\circ}{\sin 40^\circ} = \mathbf{1217.38 \text{ N}}$$


### Law of cosines

$$a^2 = b^2 + c^2 - 2 \cdot b \cdot c \cdot \cos \alpha$$

$$b^2 = a^2 + c^2 - 2 \cdot a \cdot c \cdot \cos \beta$$

$$c^2 = a^2 + b^2 - 2 \cdot a \cdot b \cdot \cos \gamma$$

Diagram of forces



The calculation of an angle in degrees ( $^\circ$ ) or as a circular measure (rad) is done with the help of inverse trigonometric functions, e. g. arcsine.


Transformation, e. g.

$$\cos \alpha = \frac{b^2 + c^2 - a^2}{2 \cdot b \cdot c}$$

## Division of lengths, Arc length, Composite length

### Sub-dividing lengths

**Edge distance = spacing**



$l$  total length       $n$  number of holes  
 $p$  spacing

**Spacing**


$$p = \frac{l}{n+1}$$

**Example:**

$l = 2 \text{ m}; n = 24 \text{ holes}; p = ?$

$$p = \frac{l}{n+1} = \frac{2000 \text{ mm}}{24+1} = 80 \text{ mm}$$

**Edge distance  $\neq$  spacing**



$l$  total length       $n$  number of holes  
 $p$  spacing       $a, b$  edge distances

**Spacing**


$$p = \frac{l - (a + b)}{n - 1}$$

**Example:**

$l = 1950 \text{ mm}; a = 100 \text{ mm}; b = 50 \text{ mm};$   
 $n = 25 \text{ holes}; p = ?$

$$p = \frac{l - (a + b)}{n - 1} = \frac{1950 \text{ mm} - 150 \text{ mm}}{25 - 1} = 75 \text{ mm}$$

**Subdividing into pieces**



$l$  bar length       $s$  saw cutting width  
 $z$  number of pieces       $l_r$  remaining length  
 $l_s$  piece length

**Number of pieces**

$$z = \frac{l}{l_s + s}$$

**Example:**

$l = 6000 \text{ mm}; l_s = 230 \text{ mm}; s = 1.2 \text{ mm}; z = ?; l_r = ?$

$$z = \frac{l}{l_s + s} = \frac{6000 \text{ mm}}{230 \text{ mm} + 1.2 \text{ mm}} = 25.95 = 25 \text{ pieces}$$


**Remaining length**

$$l_r = l - z \cdot (l_s + s)$$

$$l_r = l - z \cdot (l_s + s) = 6000 \text{ mm} - 25 \cdot (230 \text{ mm} + 1.2 \text{ mm}) = 220 \text{ mm}$$

### Arc length

**Example: Torsion spring**



$l_a$  arc length       $\alpha$  angle at center  
 $r$  radius       $d$  diameter

**Arc length**

$$l_a = \frac{\pi \cdot r \cdot \alpha}{180^\circ}$$


**Example:**

$r = 36 \text{ mm}; \alpha = 120^\circ; l_a = ?$

$$l_a = \frac{\pi \cdot r \cdot \alpha}{180^\circ} = \frac{\pi \cdot 36 \text{ mm} \cdot 120^\circ}{180^\circ} = 75.36 \text{ mm}$$

$$l_a = \frac{\pi \cdot d \cdot \alpha}{360^\circ}$$

### Composite length



$D$  outside diameter       $d$  inside diameter  
 $d_m$  mean diameter       $t$  thickness  
 $l_1, l_2$  section lengths       $L$  composite length  
 $\alpha$  angle at center

**Example (composite length, picture left):**

$D = 360 \text{ mm}; t = 5 \text{ mm}; \alpha = 270^\circ; l_2 = 70 \text{ mm};$   
 $d_m = ?; L = ?$

$$d_m = D - t = 360 \text{ mm} - 5 \text{ mm} = 355 \text{ mm}$$

$$L = l_1 + l_2 = \frac{\pi \cdot d_m \cdot \alpha}{360} + l_2 = \frac{\pi \cdot 355 \text{ mm} \cdot 270^\circ}{360^\circ} + 70 \text{ mm} = 906.45 \text{ mm}$$

**Composite length**

$$L = l_1 + l_2 + \dots$$